



Kleertred 25

Fitting Instructions

- 1.** Check width between inside faces of the doorframe rebate and cut aluminium section to this size
- 2.** This sill requires an under door clearance of 25mm. If necessary, remove door and trim to allow for this.
- 3.** Position the assembled sill between the doorframe and mark fixing points through countersunk holes. Remove sill, drill fixing holes and insert plugs.
- 4.** Screw sill into place.

Upper Section

- 1.** Remove rubber seals from aluminium section and cut the aluminium to the door width.
- 2.** With door closed measure between exterior doorframe rebate less 6mm for deflector endcaps.
- 3.** Notch the front section to this dimension as illustrated. Notches at both ends need to be equal. For outward opening doors notching is not required
- 4.** Refit rubber seals leave them extending by 3mm on each side. Nip the groove ends of the seal carrier at the lock side to avoid sliding out.
- 5.** Install endcaps to each side of the deflector and screw into position on the door.